

How to Toggle Groups Using Tags in Decent Sampler

22 Oct 2024

By Frank Faruk Ceviz frankfaruksampling.site

If you're working on a sample library using Decent Sampler and need to control whether certain groups of samples are enabled or disabled dynamically, using tags to toggle groups can be an effective solution. In this guide, we'll go over how to create a button that toggles a group on and off by using tags, providing a clear and straightforward implementation.

Setting Up the Group

In Decent Sampler, a group is essentially a collection of samples that can be controlled collectively. To enable or disable a group dynamically, you can use a tag to identify that group and a button to control it. Here's how you can set up your group:

```
<group name="Slap Noise" seqMode="always" volume="-18dB" tags="slap"
enabled="0">
  <!-- Content of the Slap Noise group -->
</group>
```

In this example, we have a group called "Slap Noise" with a tag attribute set to **slap**. The **enabled="0"** attribute means the group is initially disabled.



The above example shows the Slap Noise group's on/off button.

Creating a Toggle Button

Next, you'll need to create a button that will toggle the group on and off using the `tags` attribute. Here's the XML code for the button:











```
<button x="426.0" y="327" width="40" height="20" value="0" defaultValue="0"
style="text" parameterName="Octave">
  <state name="SLAP OFF">
    <binding level="group" type="amp" tags="slap" parameter="ENABLED"
translation="fixed_value" translationValue="false"/>
  </state>
  <state name="SLAP ON">
    <binding level="group" type="amp" tags="slap" parameter="ENABLED"
translation="fixed_value" translationValue="true"/>
  </state>
</button>
```

The button has two states: **SLAP OFF** and **SLAP ON**. Each state has a binding that controls the group with the tag **slap**. When the button is in the **SLAP OFF** state, it sets the group's **ENABLED** parameter to **false**, disabling the group. When in the **SLAP ON** state, it sets the **ENABLED** parameter to **true**, enabling the group.



The above example shows the Chrorus, Phase and Octave group's on/off button.

Creating a Custom Made Toggle Button

OFF STAGE	ON STAGE
 Pitch Drift	 Pitch Drift
 Chorus	 Chorus
 Phase	 Phase
 Timbre	 Timbre
 Octave	 Octave

Utilize a graphic design program to create separate on and off PNG button images for each function. Ensure each button is exported as an individual file.

To create custom on/off buttons in graphic design software, you can start by designing two distinct visual states that represent the "on" and "off" conditions. Tools like Adobe Photoshop, GIMP, or Canva are great for this. Design two PNG images: one for the "On" state and one for the "Off" state. These images should ideally have different colors or icons to clearly show which state the button is in. Once created, you can use these images in your XML code as demonstrated in the example for toggling the "Chorus" effect.

```
<button x="630" y="154" width="102" height="20" style="image"
parameterName="Chorus" value="0">
  <state name="Off" mainImage="Images/Chorus_off_106x19@2x.png"
clickImage="Images/Chorus_off_106x19@2x.png">
    <binding level="instrument" type="effect" effectIndex="2" parameter="FX_MIX"
value="0"/>
  </state>
  <state name="On" mainImage="Images/Chorus_on_106x19@2x.png"
clickImage="Images/Chorus_on_106x19@2x.png">
    <binding level="instrument" type="effect" effectIndex="2" parameter="FX_MIX"
value="1"/>
  </state>
</button>
```

This button uses custom images for the on and off states, providing a more engaging and visually distinct interface for your users.

Putting It All Together

By combining the group and button elements, you now have a fully functional toggle that enables or disables the "Slap Noise" group. This approach is ideal for giving the user control over different layers or effects in your Decent Sampler patch without needing complex scripting.

Tips for Success

- Make sure the tag used in the group (**tags="slap"**) matches exactly with the tag specified in the button's binding.
- Start with **enabled="0"** to ensure the group is initially disabled unless the user explicitly enables it.

Using tags for toggling groups in Decent Sampler is a clean way to manage dynamic sound layers, providing flexibility to both the developer and the end user.